



POWERHOLD

CARPET PAD CEMENT

Cemento del cojín de alfombra

DESCRIPTION:

POWERHOLD 115 Pad Cement is a fast tacking, latex-based synthetic rubber adhesive, formulated to bond carpet padding to floors to facilitate the installation of carpet. POWERHOLD 115 has good initial tack and high strength to prevent movement of padding during stretching or subsequent use.

USE WITH:

May be used with all types of sponge rubber, foam rubber, primed and bonded urethane as well as jute and hair cushions. Normally used under both sides of all seams, around perimeter and in selected field areas where needed.

FOR INSTALLATION OF:

Used over: APA registered underlayment grade plywood, and above, on, or below grade concrete in the absence of hydrostatic pressure, excessive moisture or alkalinity. The pH level of concrete must be between 5 and 9 (do not install if over 9) and moisture level of concrete must be below 5 lbs./1150 sq. ft./24 hours using an anhydrous calcium chloride test kit according to ASTM F-1869 test method.

PRIOR TO INSTALLATION:

Floor must be clean, level and dry. Remove all foreign substances such as wax, grease, dirt and any substance or chemical that would interfere with a good bond. Fill all holes and cracks with a cement based patching compound. Sand high spots, install felt or hardboard underlayment over tongue and groove flooring to eliminate the possibility of telegraphing. For best results, the installation site, floor covering and adhesive should be 65°F (18°C) or above for 24 hours before, during and after the installation.

INSTALLATION INSTRUCTIONS:

1. Using spout, apply beads of adhesive about 1/8" wide, 3" to 4" away from each wall and in a crisscross pattern the full length of all pad seams
2. Spread adhesive with a thin scrap piece of carpet.
3. Allow the adhesive to dry one to two minutes before

laying the pad.

4. Lay the padding into the tacky adhesive and apply pressure by walking over the adhesive area.

5. Proceed with the installation of the carpet immediately after laying padding. Carpet may be stretched immediately without waiting.

6. Use soapy water while the adhesive is wet. Use Touchdown #9 Adhesive Remover/Stripper if adhesive is dry.

COVERAGE:

Up to 900 linear feet of 1/8" bead per quart.

CAUTION:

DO NOT take internally. If swallowed, DO NOT induce vomiting. Call a physician immediately. KEEP OUT OF REACH OF CHILDREN.





115

TECHNICAL SPECIFICATIONS

For Product No.: 115
Powerhold Trade Name: Pad Cement, Latex
VOC's: 25
Base: Synthetic rubber, resin
Color: Beige
Consistency: Low viscosity
Open Time: up to 20 minutes
Flammability: Non Flammable
Freeze Thaw Stability: Not stable
Clean Up -
When Adhesive is wet: Warm soapy water
When Adhesive is dry: POWERHOLD Cleaning Solvent

PACKAGING

12 - 1 Gallon (3.785L) White Plastic Bottles

SHELF LIFE

1 - Year when stored in original, unopened container

COVERAGE (APPROXIMATE)

Up to 900 linear feet of 1/8" bead per quart